

1. Mark the wall fixing positions and drill holes to suit the anchors.
2. Install the anchors and the mounting bracket, then secure with screws.
3. Install the towel bar to the mounting brackets. Tighten set screws with Allen key.

